

Supplies used:

- Prep Patch Film or vinyl
- 5 x 7 inch hoop
- Mylar
- Balsa wood sticks 1/8 inch (3mm)
- Puff Stuff
- Painters tape, T-pins, scissors
- Ribbon
- Glue gun
- Stain Glass design (4.95"w X 4.95"h)




Step 1

Hoop Prep Patch film or vinyl tightly. Run the outline stitch. Mark the edge of the hoop with a small piece of tape so you know which direction to put the hoop back on. You'll need this later.




Step 2

Lay a piece of mylar over the stitches. Secure the corners with painters tape. Run the design.




Step 3

Continue running the design, trim threads as you go



Step 4

When the design is complete, remove from machine, tear away the excess mylar



Step 5

Cut two small pieces of ribbon, fold in half and glue/tape at the stitch placement marks



Step 6

Cut the balsa wood to fit along edges creating a frame



Step 7

Tape the Puff Stuff on top. Make sure you place the hoop back on the machine in the correct direction



Step 8

Run the rest of the design



Step 9

Remove from hoop and cut away the excess Puff Stuff. Tear away the Prep Patch Film or vinyl



Step 10

Run under water until the Puff Stuff has disappeared, set aside to dry

